P4 Single Stage Nomenclature

Series
Q = P4 Series

Low-Speed Shaft Orientation
H = Horizontal

Transmission Direction
P = parallel

Size (C-G)

Number of Stages (only 1)

Shaft Arrangement
I = on horizontal plane • **W** = on vertical plane

Q H P D 1 W - L R N - 4.5

High-Speed Shaft Extension
L = left • **R** = right

Low-Speed Shaft Extension
L = left • **R** = right *(must be opposite of previous)*

Low-Speed Shaft Type
N = solid

Nominal Ratio